

Original instructions

# Evaporative AIR COOLER

## buddy



## Owner's Manual & Warranty Card

### IMPORTANT READ AND SAVE THESE INSTRUCTIONS.

Please keep this important manual in a safe place.  
It is the owner's responsibility to ensure that regular maintenance is  
carried out on this evaporative cooling product.

natural cooling

**Symphony®**

[www.symphonylimited.com](http://www.symphonylimited.com)



## Safety!

Read carefully prior to attempting to assemble, install, operate or maintain the unit.

- Read and save these instructions. Do not throw these instructions away
- Complete the unit assembly before attempting to operate.
- Interference with and operation of this cooler in any manner not prescribed by these instructions could cause a safety issue and WILL void any warranty.

## Warnings

### WARNING Operation:

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not use cooler on uneven or unstable surfaces.
- Do not overfill. Use water only.
- Do not operate cooler with Rear Filter Panel removed.
- Do not insert any foreign objects or body parts into the air inlet or outlet, otherwise bodily injury or property damage may occur.
- Do not use immediately adjacent to heat sources such as stoves or radiators.
- Do not use immediately adjacent to sources of water, such as swimming pools, hot tubs, bathtubs, showers, sinks or other liquids.
- Do not operate this product near an open flame or the product may ignite and cause fire, resulting in bodily injury or property damage.
- Do not operate in areas where gasoline, paint or other flammable liquids or vapours are used or stored.
- Do not allow children to service this cooler.

### WARNING Electrical:

- All electrical connections must comply with local construction and safety regulations and be performed by qualified personnel.
- Make sure that the power switches are in the off position before connecting and operating your cooler.
- Do not use this product with any solid- state speed control device.
- Keep the cord away from heated surfaces.
- Do not operate cooler with a damaged cord, plug or other components.
- Do not step on or roll over the USB Cable with heavy or sharp objects.
- Do not run the USB Cable under carpet or other floor covering. Arrange cord away from traffic area and where it will not be tripped over.
- If the USB Cable is damaged, it should be replaced by a service agent or qualified personnel to avoid risk of bodily injury or property damage.

- Use only qualified electricians for replacement or servicing of switches, or electrical motors and components in this cooler.
- If damaged, discard cooler or return to an authorized service facility for examination and/or repair.
- Always unplug the USB Cable receptacle when the air cooler is not in use, before adding water, before cleaning, before maintenance or before moving to another location.
- Do not plug the cord into electric outlet with wet hands or an electric shock may result. The same applies for unplugging.

### **WARNING Maintenance:**


- Never wash the unit cabinet with a high-pressure hose. water may harm the motor and electrical system.
- Never attempt to disassemble or alter the product in any way not instructed by this manual. Shock, fire, or bodily injury may occur.

Stagnant water may cause bacterial growth and serious health problems.

Do not allow stagnant water to remain in the tank.

- Drain and clean the water tank before storage, after seasonal use and whenever the unit is not used for a long period of time.


## **How to install and operate cooler**




- 1.** Product on a flat surface such as a table or desk. Attach USB and plug into USB adaptor / Laptop / Power bank




- 2.** Fill the water tank by gently pouring water or add ice for more cooling from back side water inlet door.




- 3.** Touch the  button to turn product ON It will default to low speed mode

1st touch : Power on, Low speed  
 2nd touch: Medium speed  
 3rd touch : High speed  
 4th touch : Power off




- 4.** use the air direction tab to adjust airflow up/down to your preference.



**Note:**  
 Do not tilt the product after filling with water


## Maintenance Tips

- 1) Disconnect the USB Cable before servicing or maintenance.
- 2) Do not interfere with any of the electricals, and keep away from moving parts.
- 3) To clean the tank, remove drain plug. Drain out all the residual water, and push drain plug back in firmly. Draining out of stagnant water regularly from tank is necessary to keep your environment hygienic.
- 4) To clean the cooling pad, unplug the cooler; using a garden hose outside, apply low-pressure water over the cooling pad.




- 5) Under no circumstances, should customer open the cooler.
- 6) Always use clean tap water.

## How to replace cool pad



- 1.** Press and hold on top side as direction shown in images



- 2** Pull back panel top to open as shown in image




- 3** We recommend weekly cleaning of your product and cool pad to keep in best working condition, and replacing the cool pad every 3-6 months.

- Do not carry product when filled with water, Some water may remain in unit even if tank is empty.
- Use only clean water. If needed, use distilled water.
- Please read and follow regular maintenance as recommended in "Maintenance" section of this guide.
- product works best in non-polluted areas. Large dust/dirt particles may reduce lifetime of unit.
- We recommend use only in dry locations. If using in a moist area or environment, take care not to get water on external areas of the product.
- If a leak or spill occurs on the surface of device, unplug product and let it dry . Then, use as normal.
- Do not place in direct sunlight for extended period of time.
- Before not using product for extended periods of time, empty the water tank, turn unit on, and set to highest fan speed for at least 4 hours. This will dry out then and inside of your unit.
- Only use the original USB cable supplied in package.
- Do not touch the power supply or USB cable with wet hands
- Unplug product when cleaning, removing/replacing filter, or moving the device
- For best results, place product on a higher surface like a table or counter top and nearer to user
- Do not place product near a heater or any electrical equipment.
- Do not place the device in passageways or high traffic areas where there is a possibility of tripping or knocking it over.
- Do not allow any foreign objects inside product
- Do not place items on top


## Specification

- DC 5V Input
- C-Type USB port and cable
- 3-Speed

## Product part description



USB power slot



Drain plug  
at bottom side

Rubber pad



USB Cable

## **Symphony Limited**

Symphony House, FP12-TP50 Bodakdev, Off SG Highway, Ahmedabad 380059, India.  
E-mail : [services@symphonylimited.com](mailto:services@symphonylimited.com)

natural cooling

**Symphony**<sup>®</sup>

[www.symphonylimited.com](http://www.symphonylimited.com)