

# SURROUND

## BLADELESS TOWER FAN




*Before use of this product please read and preserve these important instructions.*

natural cooling


**Symphony®**

[www.symphonylimited.com](http://www.symphonylimited.com)

Product parts name



Surround i/B




Surround, Surround Jr,  
Surround Sr.


Electrical specification (220-240V, 50Hz, 1PH)

Model name	Surround	Surround i	Surround B	Surround Jr.	Surround Sr.
Watts	135	135	85	100	220


## Wiring diagram




Surround




Surround B



Surround Jr.




Surround i




Surround Sr.

## Operation

### For Surround (Knob Version)




Turn to change the fan speed between high, medium and low.




Turn to activate the swing mode. The airflow will gently swing from left to right. The vertical direction of the airflow can be adjusted manually.

### For Surround i (Remote Version)



Control panel



Remote



Press to turn the tower fan On and Off



Press to change the fan speed between low, medium and high. The currently selected fan speed will be illuminated.




WHILE THE UNIT IS RUNNING: Repeatedly press the timer button to select in how many hours the unit should turn off, upto a maximum of 7 hours. The duration of the timer is shown by the addition of the illuminated timer lights i.e. 2hr + 1hr = 3 hours.



Press to activate the swing mode. The airflow will gently swing. Upper body rotates on sturdy base. The vertical direction of the airflow can be adjusted manually. The Swing symbol will be illuminated when the function is active. Press again to turn it off.

### For Surround B



Press to turn the tower fan On and Off



Press to change the fan speed between low to high. It is 7 speed options. The currently selected fan speed will be illuminated.



WHILE THE UNIT IS RUNNING: Repeatedly press the timer button to select in how many hours the unit should turn off, upto a maximum of 7 hours. The duration of the timer is shown by the addition of the illuminated timer lights i.e. 2hr + 1hr = 3 hours.




Press to activate the swing mode. The airflow will gently swing. Upper body rotates on sturdy base. The vertical direction of the airflow can be adjusted manually. The Swing symbol will be illuminated when the function is active. Press again to turn it off.

## Warning

1. Unplug and disconnect the fan from power source before attempting any maintenance or service
2. If the supply cord is damaged, it must be replaced by the manufacturer, its service provider in order to avoid hazard. Do not operate the product with a damaged power cord or plug.
3. To avoid electric shock, connect only to an outlet provided with a ground fault interrupting device. (ELCB = Earth leakage current breaker)
4. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
5. Children of less than 3 years should be kept away unless continuously supervised.
6. Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance
7. Children must not be allowed to play with fan.
8. This appliance is not intended to be used in locations where special conditions prevail, such as the presence of a corrosive or explosive atmosphere (vapour or gas).
9. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.



This marking indicates that this product should not be disposed off with other household wastes throughout the EU and other applicable countries. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly. If you wish to discard this product please contact your local authorities or dealer from where it was purchased and ask for correct method of disposal.



Symphony appliances work on inverter. The inverter should be of sine-wave type of appropriate rating.

## WARRANTY REGISTRATION CARD

Product Sr. No.

Date of Purchase \_\_\_\_/\_\_\_\_/\_\_\_\_

Model : \_\_\_\_\_

Name : \_\_\_\_\_

Address : \_\_\_\_\_

E-mail : \_\_\_\_\_

Mobile : \_\_\_\_\_ Phone : \_\_\_\_\_

### Condition of warranty

We extend this limited warranty to the original buyer (first retail purchaser) and warranty that the product shall be free from manufacturer defects in workmanship and materials for 12 months from the date of purchase. a. Warranty will come in with effect when the following conditions are met with a) Warranty registration card duly filled and received by the company within 10 days from the date of purchase. b) Product is operated following the recommendations explained in-side the user manual. b. The company's liability under the warranty will be limited only to motor, oscillate motor, remote, PCB and restricted to any such defect which occurs under conditions of normal operations and under proper use. Any part/s replaced by the company at its discretion shall be a functionally operative unit. c. This warranty shall not apply to product: 1) Which have not been purchased from authorized distributor through their network or company's authorized retail stores, 2) Which have been altered / opened by any other personnel not authorized by the company, 3) Incorrectly used in combination with any other substance or products, 4) Which are used for rental purpose and / or which develops problems due to faulty care or maintenance and alterations to product or its parts. 5) Which is subjected to electrical supply for which the product is not designed, 6) Warranty will void if the product is operated with a sub-standard inverter or non-sine wave inverter. 7) If documentation of buying is not available to validate an original purchase. d. While the company will make every effort to carry out the repairs at the earliest, it however is made expressly clear that the company is under no obligation to do so in a specified period. e. This warranty shall automatically terminate on expiry of the warranty period of 12 months from the date of purchase even if the product may not be used for any time during the warranty period for any reason whatsoever. f. Outer plastic parts are not covered under warranty. g. The company shall not be liable in any case for any loss or damage caused to any property, death or disability caused to any human life arising out of fire, electrical fault, short circuit, accidental handling or any kind of natural calamity. As, such the company's liability is limited to the cost of the spare parts of the said products only. h. Change of address of the customers must be intimated to the company without which the warranty shall not be operational. i. Due to ongoing research and development, the company holds the rights to modify the product without any prior notice or obligation to buyers. j. Purchaser should retain the purchase bill as evidence of the date of purchase. Copy of the purchase invoice should be given to the visiting service engineer while attending the complaint. In case of any alteration in the date of purchase invoice is found without sign and seal of the dealer, the warranty shall be void. k. During the warranty, customer is not entitled for exchange of product or refund money. l. The court/Consumer forums only at Ahmedabad, Gujarat, India shall have exclusive jurisdiction for any disputes arising out of this sale/transaction. m. Service for this product shall be provided by Authorized Service Provider. You may register warranty by log on to [www.symphonylimited.com/warranty](http://www.symphonylimited.com/warranty) Warranty will be applicable if registered within 10 days of purchase. n. The above warranty conditions shall be applicable for domestic service only to the sales in the domestic markets of India, excluding north-eastern states, Andaman & Lakshadweep. For overseas market the warranty will be given by the local distributor of the respective country.

Company has four types of call registration facilities for customers.

1. Warranty registration through Website - visit [www.symphonylimited.com/warranty-registration](http://www.symphonylimited.com/warranty-registration)
2. Registration through Customer Care number – 9510976161
3. Registration through WhatsApp – 9510976161 only for customer.

### Symphony Limited

Symphony House, FP12-TP50 Bodakdev,  
Off SG Highway, Ahmedabad 380059, India.

E-mail : [services@symphonylimited.com](mailto:services@symphonylimited.com)

Dealer's name  
& signature

**FOR SERVICE / WARRANTY REGISTRATION (INDIA)**



[symphonylimited.com/care](https://symphonylimited.com/care)



Call

OR



WhatsApp 'Hi' on

**9510976161**

## **Symphony Limited**

Symphony House, FP12-TP50 Bodakdev, Off SG Highway, Ahmedabad 380059, India.  
E-mail : [services@symphonylimited.com](mailto:services@symphonylimited.com)

**natural cooling**

**Symphony®**

[www.symphonylimited.com](https://www.symphonylimited.com)